



DESERTTECH®
◀ TOMORROW'S WEAPONS ▶

SRS M2 Top Rail Installation Instructions

Remove the SRS A2 top rail by loosening the 6 screws fastening A2 Rail in place. Hold on to these, you will need them later.

With 3 3/8 Button Head Cap Screw, and 3 M-LOK T-Nuts, Fasten the M2 Top Rail to the A2 Handguard – **Torque to 24in. Lbs.**

With the original 6 screws removed from the SRS A2 Top Rail, place the remaining screws into the top rail holes – **Torque to 24in. Lbs.**

Parts Included:

Screw, 10-24 x 3/8 Button Head Cap Screw – 3 qty

M-LOK T-Nut – 3 qty

SRS M2 30MOA 550mm Full-Length Top Rail – 1 qty